

Streetware Decorative Columns

Installation

A detailed installation instruction sheet is available from CSP Pacific, however, we have included brief details below. The columns are freighted in one (6.5m mounting height only) or two pieces - pole and outreach packed separately (6.5m and 8.5m NMH options).

Equipment Required - Lifting equipment such as a Hiab, cherry picker or crane.

Site Preparation - Assembly should be undertaken on a level area with the pole base as close as is practical to its final position.

Accessories - Lantern and outreach (removable outreach option only), can be fitted before or after erection depending on site conditions and the availability of equipment. It may be preferable to run and fix the electrical cables as assembly proceeds depending on the fixing method. Decorative footings (optional) must be slid over the base section of the pole before erection.

Erection - Check the pole balance point, then raise until vertical and either lower into the prepared hole or onto the prepared concrete foundation. (Refer to diagram below.) For added safety and as an extra aid for handling, it is suggested that an additional sling be fixed from the lifting point to a convenient opening such as the gear opening. Care must be taken not to damage the paint.

Foundation - Ground planted - The pole should be planted to the depth as recommended by the Local Authority, which is generally not less than 15 percent of its overall length. After checking vertical alignment, backfill with concrete, granular material, or selected excavated material (if loadings and conditions permit).

